

TRIPOD (Z25) 2 SE UTC-9(-8DT) N59°15.79' W158°33.47'

225 NOTAM FILE DLG

RWY 11-29: 1250X50 (TURF-GRVL)

RWY 11: Trees.

RWY 29: Trees.

RWY 18-36: 850X40 (GRVL-DIRT)

RWY 18: Trees.

RWY 36: Trees.

AIRPORT REMARKS: Unatndd. Rws not maintained; recommend prior inspection before use. Rwy 18-36 has 7' trees growing in the center of the rwy midfield. Rwy unusable for fixed wing acft. Rwy 11 forest with 32' trees 0' from threshold. Rwy 36 forest across entire apch up to 0' of threshold. No rwy markings either rwy. Rwy 11-29 is very rough and overgrown with brush and trees. Rwy 11-29 sfc consists of a narrow ATV trail and undulating tundra which slopes downhill towards north. Rwy 18-36 surface is very uneven and occasionally very soft. Rwy 18-36 used as an ATV camping site. Rwy 18-36 unusable only 10 ft wide with 6-12 ft trees encroaching & rocks to 10 inches on sfc.

COMMUNICATIONS: CTAF 122.9

KODIAK

ALITAK SPB (See LAZY BAY on page 158)

ALL WEST (See DELTA JUNCTION on page 90)

ALLAKAKET (6A8)(PFAL) 1 SSE UTC-9(-8DT) N66°33.11' W152°37.33'

441 B NOTAM FILE FAI

RWY 05-23: 4000X100 (GRVL) MIRL

RWY 05: Brush.

SERVICE: LGT ACTVT MIRL Rwy 05-23—CTAF.

AIRPORT REMARKS: Unattended. Rwy condition not monitored, recommend visual inspection prior to landing. Snow removal ops during winter, monitor CTAF. Rwy 05-23 marked with lgts and cones. Rot bcn may not be observed from northern quadrants at low altitudes. Cold temperature airport. Altitude correction required at or below -43C.

AIRPORT MANAGER: (907) 451-5280

COMMUNICATIONS: CTAF 122.9

BETTLES RCO 122.2 (FAIRBANKS RADIO)

Ⓡ **ANCHORAGE CENTER APP/DEP CON 124.6**

RADIO AIDS TO NAVIGATION: NOTAM FILE BTT.

BETTLES (H) (H) VOR/DME 116.0 BTT Chan 107 N66°54.30' W151°32.15' 211° 33.5 NM to fld. 637/20E.

VOR AZIMUTH & DME unusable:
047°-077° byd 24 NM

COMM/NAV/WEATHER REMARKS: For a toll free call to Fairbanks FSS dial 1-866-248-6516.

FAIRBANKS

H-1A, L-4I

IAP

